

[SELECT]

- Enter sub modes
- >2 sec. = enter setup
- Setup: move

[MODE]

- TIME → SAIL →
- BARO → COMP →
- Return to main mode
- Accept and exit setup
- >2 sec. = light



[-BUTTON]

- Quick view of compass
- Synchronize sailing timer
- Compass bearing tracking
- Scroll logbook & memory information

[+BUTTON]

- In TIME mode Date → Seconds
- Sailing Timer: Start / Stop
- Setup: Increase (+)


SUUNTO

MARINER, YACHTSMAN, REGATTA

POCKET GUIDE




SUUNTO
www.suunto.com



HOW TO DO

SET SAILING TIMER ① Mode = SAIL ② Press [-BUTTON] until desired countdown period appears

START / STOP SAILING TIMER ① Mode = SAIL ② [ON OFF] to start ③ 2x [ON OFF] to stop

SET REFERENCE BAROMETRIC PRESSURE (for pressure difference measurement)

① Mode = BARO ② [SELECT] ③ [SELECT] > 2sec. ④ [+] or [-] to reset or retain old setting

⑤ [MODE] to accept

CALIBRATE COMPASS ① Mode = COMP ② 2 x [SELECT] ③ [SELECT] > 2sec. ④ [-]

⑤ hold level, rotate 360° ⑥ repeat 4 and 5 if text PUSH - is displayed until text done emerges

⑦ 2 x [MODE] to return